

INSTRUCKTIONS FOR PAKOL

1. Carefully clean the thread for dirt and oil, use for instant white spirit. Please see material safety sheet.
2. Steer/shake PAKOL thoroughly before use.
3. The clean thread is brushed with a layer of PAKOL. If convenient you can also brush the muff with PAKOL.
4. The flax is now winded even and tightly onto the thread, from the pipe-end and in. (Rising with the thread.)
5. Applicate an even layer off PAKOL on the winded joint, if needed twice with one minute interval. IMPORTANT! The flax must be soaked in PAKOL.
6. Let PAKOL dry 10 min. before assembling.
7. The joints now have to dry 12-24 hours (depending on the surrounding temperature) before taking into use.(Very important, when dealing with diesel or fuel oil).
8. Make sure to have good ventilation in the working process. Seal the packaging immediately after use.

Attention:

The above information is given on basis of tests and experience. As we do not have the control over the usage of the product, it is recommended to make a test installation to make sure, that the product is suitable for the wanted installation.