

INSTRUCTIONS FOR TEFLONTAPE

1. Clean and chamfer the thread where you wish to use the tape.
2. The tape is now winded on to the thread from the pipe-end and in. (rising with the thread). Make sure to tighten the tape as much as possible without breaking it.

Depending on the chosen tape-type and the thread-tolerance use a suitable amount of tape. Using a tape with low density you need more rounds on top of each other, tapes with more density an overlap of 50% is usually enough.

3. Now fit the joints in a way that leaves a pair of threads visible when fully fitted. Please note that tapes with density under 1,0g/cm³ do not allow backwards adjusting – whereas tapes with higher density, such as Multitape, Sealrite and Top-seal, all allows a backward adjustment off 45 degrees - equaling ¼ round.

Attention:

The above information is given on basis of tests and experience. As we do not have the control over the usage of the product, it is recommended to make a test installation to make sure, that the product is suitable for the wanted installation.