

# Instruction for UNIGUM

## Instruktion for use:

**1.** Roll an appropriate amount off UNIGUM to a suitable length and thickness depending on the task.

When packing between table and Kitchen Zink the thickness should be approximately  $\frac{1}{2}$  - 1 cm. When packing a drain fitting the layer should be a little thinner, depending on the size of the joint of course.

Clean the area where the joint is placed for dirt and gravel.

**2.** Turn the Zink or drain-fitting upside down and place the Unigum on the edge all-way round (see drawing).

Fit the Zink or drain fitting and tighten until you flatten the UNIGUM.

Surplus UNIGUM can be removed by rubbing it or cut with a knife.

**3.** Packing of a bowl is carried out by pressing a suitable amount of UNIGUM into the gab between the bowl and the drain.

Make sure that the gab is filled and airtight.

**4.** Put surplus UNIGUM back into a airtight plasticbag.

