

INSTRUCTION FOR UNIFLON P.T.F.E.

Resistant to all known liquid and gasses.
Approved* for drinking water, gas and oxygen.

USE:

1) **Start winding criss-cross from the tube end app. 10-15 cm. of the thread, more at start. Add a few drops off fluid from the red dispenser on to the thread sealant. (See data-sheet).

2) Now fit the joints in a way that leaves a pair of threads visible when fully fitted. Uniflon allows a backward adjustment off 45 degrees - equaling $\frac{1}{4}$ round.

*Drinking water and gas: EN 751-3
Oxygen: BAM; II-2742/2004E

** $\frac{1}{2}$ +12-18 winds
 $1\frac{1}{2}$ +18-24 winds